


P-Star 25K50 Micro

Pinout and Peripherals



ⓘ Pull-ups available on Port B and $\overline{\text{MCLR}}$.

External power input	EUSART
Power distribution	MSSP (SPI and I ² C)
Ground	PWM outputs
I/O pin names	Interrupts
ADC channels	Other functions
Comparator	LEDs

* Function can only be used if bootloader is erased.

