


P-Star 25K50 Micro

Pinout and Peripherals



ⓘ Pull-ups available on Port B and $\overline{\text{MCLR}}$.

| | |
|----------------------|---------------------------------|
| External power input | EUSART |
| Power distribution | MSSP (SPI and I ² C) |
| Ground | PWM outputs |
| I/O pin names | Interrupts |
| ADC channels | Other functions |
| Comparator | LEDs |

* Function can only be used if bootloader is erased.

